



KT	1	-1	
	2	-2	
	3	-3	
	4		
	5	-18	
	6	-19	
	7	-31	
	8	0	
	9	-135	
	10	-137	
	11	-139	
	12	0	
	13	-141	
	14	-143	
	15	-145	
	16	-147	
	17		
	18		
	19	-4	
	20	-5	
21	-18		
22	-19		
23	-33		
24	-34		
25	-35		
26	-36		
27	-37		
28	-38		
29			
30	-151		
31	-153		
32	-155		
33	-157		
34	-159		
35	-171		
36			
37	0		
38	0		
39			
40	101		
41	103		
42			
43			
44			
45			

13	UF	变频器	ACS500-01-145A-4	1
12	UF	变频器	ACS500-04-560A-4-250W	1
13	PR	电位器	10K Ω 3W	2
11	SHO	按钮	LA88-111/2	2
10	SA	转换开关	1M12-160M01/2	2
9	QP	密封断路器	NS1630V/630, NS1250V/250	2
8	PF	频率表		2
7	PA	直流感流表		2
6	RM	接触器	LC1D62MC, LC1D80M7C	2
5	UF, KO, 4	中间继电器	RMA1B207 AC230V	2
4	RM12	指示灯	红 AC220V	4
3	RM12	指示灯	绿 AC220V	4
2	RM12	指示灯	蓝 AC220V	4
1	PI	熔断器	RT18-32/6A	4
序号	代号	元件名称	型号规格	数量

设备材料表

编号: 393

ACS

变频器柜二大图

1000\*2200\*600

河南中原黄金冶炼厂有限责任公司